

































Модель крепления	Фото крепления	Марка авто	Модель авто
438-1			Toyota: Camry V (2002-2006), Camry VI (2006- ...), Camry V40, V41, Reiz, Corolla (2001-2006), Previa, Crown, RAV4 (2000-2006), Land Cruiser Prado
			Ford: Mondeo/Focus/S-MAX/
			Mazda 3, 5, 6 ( - 2007), Tribute (2000-2009), MP5 (1990 - 2006), 626 (1972-2002), CX7 (2006 -...), CX9 (2007 - 2009)
			Chevrolet: Cruze, Cruze, Tahoe (2007 г.в.-... ), Spark
			Nissan: X-Trail, Teana, Qashqai, Tiida, Sunny, Bluebird, Sylphy, Livina, March
			Mitsubishi: Lancer 9, Lancer X, Outlander, Outlander XL, Pajero, ASX , L200 (2010-...), Pajero Wagon 3, 4, Pajero Sport (2010-...)
			Cadillac 08.09 Escalade, CTS08.09
			Honda: Accord; Civic 5D VIII (2006 -...), Pilot
			Lexus: большинство моделей
			Chery: Tigo
			Crysler: Pacifica, Sebring (2006 -...)
			Jeep: Cherokee (1986 - 2001), Liberty (2001-2007)
			Kia: Ceed, Cerato (2010 -...), Koupe, Rio, Soul
			Suzuki: Liana, Grand Vitara (2005 -...), Swift, Kizashi, SX4 sedan
		438-2	
	Mistubishi: Grandis, Galant		
	Subaru: Forester, Legacy, Impreza, Outback		
438-3			Volkswagen: Passat, Bora 09, Jetta, Santana, Tiguan, Touran, Toureg, Phaeton, Magotan, Golf, Polo, Lavida
			Audi : A1, A3, A4, A5, A6, A7, A8, A6L, Q3, Q5, Q7, TT, RS
			Skoda: Superb, Fabia, Octavia, Fabia combi, Roomster, Yeti
438-4			Chevrolet: Spark, Lova
			GM: Excelle
438-6			Chevrolet: Epica, New sail, Cruze, Orlando

			Ford: Fiesta
438-7			Hyundai: Sonata, Elantra/Tucson/I30/
			MG6, MG7
			Kia: Cerato, Forte, Rio, Sportage, Soul
438-8			Honda: City
438-12			Citroen
			Volvo: большинство моделей
			Peugeot: 307, 207, 407
			Renault: Большинство моделей
438-14			Toyota: Camry V (2002-2006), Camry VI (2006- ...), Camry V40, V41, Reiz, Corolla (2001-2006), Previa, Crown, RAV4 (2000-2006), Land Cruiser Prado
			Ford: Mondeo/Focus/S-MAX/
			Mazda 3, 5, 6 ( - 2007), Tribute (2000-2009), MP5 (1990 - 2006), 626 (1972-2002), CX7 (2006 -...), CX9 (2007 - 2009)
			Chevrolet: Cruze, Tahoe (2007 г.в.-...), Spark
			Buick: Regal/Park Avenue/La Crosse
			Nissan: X-Trail, Teana, Qashqai, Tiida, Sunny, Bluebird, Sylphy, Livina, March
			Mitsubishi: Lancer 9, Lancer X, Outlander, Outlander XL, Pajero, ASX, L200 (2010-...), Pajero Wagon 3, 4, Pajero Sport (2010-...)
			Cadillac 08.09 Escalade, CTS08.09
			Honda: Accord; Civic 5D VIII (2006 -...), Pilot
			Lexus: большинство моделей
			Chery: Tigo
			Crysler: Pacifica, Sebring (2006 -...)
			Jeep: Cherokee (1986 - 2001), Liberty (2001-2007)
			Kia: Ceed, Cerato (2010 -...), Koupe, Rio, Soul
			Suzuki: Liana, Grand Vitara (2005 -...), Swift, KIZASHI, SX4 sedan
	Lada		
	Hyundai: IX30, IX35, IX55, Elantra V (2011 -...), Accent (2010 -...), Solaris, Sonata, Genesis / EQUUS		
438-15			Fait: большинство моделей
			Mercedes: большинство моделей